

New Features in ShipWeight 13.5

Contents


Main window	2
Adjust total.....	2
Include Custom Code in Main window	2
Change Field Value.....	3
Options window	3
General tab	3
Wgt.grps tab.....	3
Quantity tab	3
Log tab.....	3
Estimation tab	4
Parameter Definition window.....	4
Parameters window	6
Items window.....	8
Project Type window	8
Weight Distribution window.....	9
Estimation window	10
Export Historical Database window	10
Other new features.....	10
Enhanced logbook functionality	10
Summation of Custom Codes.....	14
Calculations.....	14
Updates to the help functionality.....	16
Possible to overwrite existing project	16

Main window

The Main window has been improved with the following functionality: adjusting totals can now create an item, Custom Codes can be selected as one of the fields shown in the Main window, there is a new edit option “Change Field Value” for the Main window - this window is the same as the Change Field Value Window used in the Items window. In the following sections it is described how to utilize these new functionalities.

Adjust total


When using the adjust total function check the checkbox “Create Item” to create a new item instead of adding the adjusted weight to a cell in the Main window view.



	Wgt.grp	Percentage	Description	Weight	VCG	LCG	TCG	VCG_min	VCG_max	LCG_min	LCG_max	TCG_min	TCG_max
A			<New total weight>	4 000.000	5.000	65.000	0.000	0.000	15.000	-5.000	120.000	-15.000	15.000
B	LW		Lightship	3 640.910									
C=A-B			Total correction	359.090	5.000	65.000	0.000	0.000	15.000	-5.000	120.000	-15.000	15.000
D	R	100.00%	Remainder	359.090	5.000	65.000	0.000	0.000	15.000	-5.000	120.000	-15.000	15.000
E=C-D			Not assigned correction	0.000	0.000	0.000	0.000	0.000	15.000	-5.000	120.000	-15.000	15.000

Include Custom Code in Main window


Right click in the Main window and select Show Fields. To select the Custom Code to be shown in the Main window, check the checkbox next to it. The position for the different fields is assigned by drag and drop in field list, top to bottom is shown from left to right in the Main window.



Field	Weight Group	Weight [kg]	Std.	C01 - test	VCG [m]
<input checked="" type="checkbox"/> Weight Group					
<input checked="" type="checkbox"/> Weight [kg]					
<input checked="" type="checkbox"/> Weight Std.dev.[%]					
<input checked="" type="checkbox"/> C01 - test					
<input checked="" type="checkbox"/> VCG [m]					
<input checked="" type="checkbox"/> VCG Std.dev.[%]					
<input checked="" type="checkbox"/> LCG [m]					
<input checked="" type="checkbox"/> LCG Std.dev.[%]					
<input checked="" type="checkbox"/> TCG [m]					
<input checked="" type="checkbox"/> TCG Std.dev.[%]					
<input checked="" type="checkbox"/> VCG_min [m]					
<input checked="" type="checkbox"/> VCG_max [m]					
<input checked="" type="checkbox"/> LCG_min [m]					
<input checked="" type="checkbox"/> LCG_max [m]					
<input checked="" type="checkbox"/> TCG_min [m]					
<input checked="" type="checkbox"/> TCG_max [m]					
<input type="checkbox"/> Net Weight [kg]					

Change Field Value

Select the relevant wgt.grp. node in the wgt.grp. tree and then go to the Edit menu and select Change Field Value to open the Change Field Value Window. Select which field to change and which operation to be done and then the value that corresponds to the operation you would like to do.



Options window

There have been assigned many new options in ShipWeight. Use the Options window to configure ShipWeight so that it fits you and your way of working. The improved functionalities are described under the different Tab names where they are found.

General tab

For Metric units it is now possible to select between meters[m] and millimeters[mm]. The checkbox "Autocalc. Formula Values" is new as well. Check this checkbox to automatic update calculations in Main window, Items window and for parameters when a parameter or field value updates.

Wgt.grps tab

Check the checkbox "Hide Top Wgt.grp values" to hide the values of the selected top weight group if these numbers are more confusing than clarifying. Check the checkbox "Sum All Wgt. grps" if you would like ShipWeight to sum all wgt. grps including those with status "Not Defined". If the checkbox "Questions before Summarize" is checked in addition, ShipWeight will ask before doing this summation.

Quantity tab

For the 5 different quantities in the Quantity tab, 4 new merge options are now added. These are count, average, max and min.

Log tab

It is possible to uncheck the checkbox "Show Log window at Shutdown" in the Log tab, if you would like to disable the automatic opening of the logbook, when closing the software. By doing this you also disable the automatic summary of the changes, since the project was opened, in the project.

Estimation tab

Here there are three new checkboxes, “default Filter All Parameters”, “Include All Reference Projects” and “Include database ID by default”. The checkbox “default Filter All Parameters” sets all the filters by default before opening the Estimation window, and the checkbox “Include All Reference Projects” selects all the reference vessels for the estimate. The third checkbox is used to disable the Databasetype and database ID name when a vessel should be exported to historical database. By unchecking the checkbox, “Include database ID by default”, the default ID, in the Export to Historical database window, will only contain the ProjectID.


Parameter Definition window

More flexibility and functionality have been added here in the Parameter Definition window. There are two new parameter types: link and memo parameter. If a parameter is set to link, that parameter takes in a path for where a file is located i.e., a link. On the other hand, if a parameter is set to a memo parameter this parameter can store RTF text, where it is possible to write in a formatted text. This can for example be used as input to a report created in Crystal Reports. The functionality for the composite parameter has also been increased, it is now possible to use Log10 for Reverse Polish Notation when defining a composite parameter. However, the biggest change is that it is now possible to add an image and an alias for each parameter. To add an image to a parameter, double click in the image field for that parameter and use the image viewer to add an image. An alias can be assigned to a parameter by writing the selected alias in the alias field for that parameter. This alias can then be used for defining other composite parameters in the Parameter Definition window, as part of a parameter value in the Parameters window, as a cell calculation in the Main window or as part of a calculation for an item in the Items window.

Example 1:


In this example we will add an image to a parameter.

Make ready an image stored as a .bmp-file showing the depth to main deck, stored in a location of your choice. Open the Parameter Definition window, Database | Administrator | Parameter Definition... Find the parameter Depth to main deck by filtering the list. Double click in the field Image.



ID filter	Name filter	Alias filter	Description filter	Type filter	Decimals filter	Unit filter	Symbol filter	Max filter	Alternatives filter	Expression filter	Activ...				
	hdm	Depth to maindeck		decimal	2	m	D	50.000			<input checked="" type="checkbox"/>	279	37	<input type="checkbox"/>	


Now the Image viewer appears, click the Browse button to select the file location for the image you prepared earlier. When the image is selected click the OK button to store the picture.



Example 2:

In this example we will assign an alias to Lpp and use this alias for calculating LCG for a wgt. grp in the Main window.


Open the Parameter Definition window, Database | Administrator | Parameter Definition... Use the name filter to find Length betw. Perp. and assign the alias L for Lpp. If you rather would use the ID of the Parameter in the Parameters window instead of the alias, that is possible as well.



Now L can be used for Lpp in calculations. Let's define LCG to be L/2 for E1.1 Hatches.

Weight Group	Weight [kg]	Std.d...	VCG [m]	Std.d...	LCG [m]	Std.d...
WBS500 - ShipWeight break down system						
DISP - Displacement						
DR - Remainder displacement						
DW - Deadweight	90 000					
LW - Lightship	520 130					
R - Remainder						
E - Equipment	520 130					
ER - Remainder equipment						
E1 - Equipment for cargo	520 130					
E1.R - Remainder equipment for cargo						
E1.1 - Hatches	5 130				66.90	
E1.1.R - Remainder hatches						
E1.1.1 - Cargo hatch cov., weather d.	5 000				=L/2	
E1.1.2 - Cargo hatch cov., tween d.						

This field will now show the middle of Lpp as LCG. If the "Autocalc. Formula Values" in the General tab in the Options window has been checked, this value will be updated if Lpp changes.




Set the Lpp to 140m and then change it to 130m and see that LCG for wgt.grp. E1.1.1 changes from 70m to 65m.

	Weight...	Std...	VCG [m]	Std...	LCG [m]		Weight...	Std...	VCG [m]	Std...	LCG [m]	St
n system						n system						
displacement						displacement						
ht	90 0...					ht	90 0...					
	520 ...						520 ...					
nder						nder						
nent	520 ...					ent	520 ...					
Remainder equipment						Remainder equipment						
Equipment for cargo	520 ...					Equipment for cargo	520 ...					
E1.R - Remainder equipment for cargo						E1.R - Remainder equipment for cargo						
E1.1 - Hatches	5 130				71.77	E1.1 - Hatches	5 130				66.90	
E1.1.R - Remainder hatches					70.00	E1.1.R - Remainder hatches					65.00	
E1.1.1 - Cargo hatch cov., weat...	5 000					E1.1.1 - Cargo hatch cov., weat...	5 000					

Parameters window

Here in the Parameters window the new parameter types, link, and memo, can be assigned with a link location and the text of your choice in the memo parameter. The image assigned to each parameter in the Parameter Definition window can be viewed by checking the Show Image checkbox. Mark the parameter, as shown in the picture below, to select which parameter to show the image for.




In addition to this it is now possible to write in a formula as input for a parameter in the Parameters window. An alias given in the Parameter Definition window can be used here if you would like to base the calculation on another parameter.

Example 3:

In this example we will use the alias created in Example 2 and define the Length Over All (Loa) to be $L_{pp}/0.96$.


Open ShipWeight and the Parameters window find the Loa parameter in the Main Parameters tab. Write in $L/0.96$ as the parameter value. Now we have used the Alias for L_{pp} to calculate the value for LOA.



It is possible to use the Parameter ID as well for this calculation, for L_{pp} the Parameter ID is IPE, so then the calculation would be $=IPE/0.96$.

Items window

When a global filter is activated in the Main window, this filter will be visible in the Filter bar at the bottom of the Items window. In addition to this, the Change Field Values window has been made modular with respect to the Items window. E.g., it is possible to change item selection after the Change Field Values window has been opened.




The screenshot shows the 'Items' window interface. At the top, there is a menu bar (Items, Edit, Setting, Tools, View, Window) and a toolbar. Below the toolbar, the 'ID & Description' section shows a table with one row: E1.3, Movable deck, Administrator, 9/23/2021 11:3. The 'Weight & CoG' section shows a table with columns: NoOf [-], Factor [-], Length [-], Width [-], UnitWeight [kg], Weight [kg], VCG [m], LCG [m], TCG [m], VCG_min [m], VCG_max [m], LCG_min [m], LCG_max [m]. The 'Codes' section shows a dropdown menu with 'test'. The 'Table view' section shows a table with columns: WgtGrp, ItemNo, Description, RegUser, RegDate, NoOf [-], Factor [-], Length [-], Width [-], UnitWeight [kg], Weight [kg]. The 'Total weight & CoG' section shows a table with columns: Weight [kg], Weight [t], VCG [m], LCG [m], TCG [m], VCG_min [m], VCG_max [m], LCG_min [m], LCG_max [m], TCG_min [m], TCG_max [m]. At the bottom, a filter bar is visible, containing the text: Global Filter: ((VCG < 10) AND (VCG > 5)), Local Filter: WgtGrp = 'E1.3'.

Project Type window

With the new scalable window for Project Type, it is now possible to adjust the window size. After selecting the Ship Types, they can be stored as a selection set. This selection set can be imported from a different project as a template. If you would like to print the selection set, a new Print button opens the


ShipWeight regular Print Preview window.



Weight Distribution window


A new drop-down list is now available in the Weight Distribution window, it is now possible to select a custom code weight group in addition to the default weight to be presented as the source for the weight distribution curve. Furthermore, a new “NAPA by element” export method has been added, the new method transports the items from the Weight Distribution Curve such that it fits the NAPA Element definition. The syntax for this new method is as follows: ELE <ItemNo> W LCG TCG VCG LCG_min LCG_max ‘<description>’

Example: ELE E001 125.91 0.5 0 4.55 -5.5 4.9 ‘hull below 1dk (aft - #18)’




Estimation window

In the Estimation window menu bar, it has been added a quick navigation drop down menu. This menu supports quick navigation from one wgt.grp. to another wgt.grp. from inside the Estimation window. See picture below to where to find this menu.



Export Historical Database window



For the QA-process to get more efficient it is now possible to open the Method window from the Export to Historical database window. There it is easy to check if everything you need for your historical database project is up to date. The Method window can also be opened by selecting Method Values... in the View menu in the Main window menu bar.




Other new features

Enhanced logbook functionality

Now it is possible to log weight at a certain time by marking a weight group and then selecting View | Logging | Wgt.grp. Logbook in the View menu in the menu bar in the Main window.




By clicking get wgt. grps... the weight groups data for this weight groups are added to the comment field in the Logbook window. To write this comment to the log click Add to Log.




If you throughout the project log the weight and CoG of a given wgt. grp. you can see the development in a graph in the tabs: Weight Logbook, VCG Logbook, LCG Logbook and TCG Logbook. If the graph does not show, maybe the window is too narrow. Then adjust the size of the Graph window on the top of the

Logbook window, by drag and drop in the line where you see the red arrow in the picture below.



It is also possible to see the development according to the data in the Log Database. To see these graphs, select the tabs Weight/VCG/TCG Log Database. Check the checkbox “Include Sublevel” to include the sublevel of these graphs. In the picture you see that the graph is updated with the numbers from the sublevels with corresponding legend.




In addition to this ShipWeight generate an automatic log message by analyzation of the changes in the log database since the project was opened. For this to work the option “Show Log window at Shutdown” checkbox in the Options window at the Log tab must be checked when closing the project.

Example 4:


In this example we will log the changes for a project using the new automatic generated log message.

First open ShipWeight in an empty ShipWeight Project. Add a main hull steelweight item e.g., Wgt. grp: H1, ItemNo = 1000, Description: main hull, with weight 1000000kg, VCG at 5m, LCG at 40 m and TCG at 0m. Make sure you have checked the “Show Log window at Shutdown” checkbox in the Options window at the Log tab. Then close ShipWeight and answer yes to save the project.

Standard 13.50.31.01 [ProjectDB(New Features 13-5-log)] Enterprise E... X



Now the Logbook open with an automatic generated log message showing the changes since the project opened.



Logbook

User: Administrator Wgt.grp: DISP - Displacement

Comments Weight Logbook VCG Logbook LCG Logbook TCG Logbook Weight Log Database VCG Log Database LCG Log Database TCG Log Database

Settings for standard comments are defined in Option window

Include Sublevel

Get Wgt.grps... Clear Comment

Comment: DISP - Displacement Weight is increased with 1 000 t, VCG is increased with 5.00 m, LCG is increased with 40.00 m, TCG is unchanged at 0.00 m

Weight & CoG

Weight: 1 000 X: 5.00 Y: 40.00 Z: 0.00

Add to Log Edit Delete

Date/Time	User	WgtGrp	Comment
2021.09.24 14:42:37	Administrator	H1	Weight groupWeight [t]VCG [m]LCG [m]TCG [m]VCG_min [m]VCG_max [m]LCG_min [m]LCG_max [m]TCG_min [m]TCG_max [m]

Print Close

Click Add to Log to add this automatic generated text about change to the logbook.

Summation of Custom Codes

When creating a new custom code, you must define which type of AutoSum you would like your code to use. The new column “AutoSum” in the Code Definition Table is where you define how this code should summarize. It is possible to select one of the following alternatives - no sum, sum, average, weighted average(<weighted against>), count, minimum and maximum. Previously the custom code was summed as No sum or Sum. The added alternatives give more flexibility for how the different codes present themselves in the summary footer in the Items window, and as different fields in the Main window.

Calculations

There has been an extensive upgrade of the calculations that are possible in ShipWeight. For each cell that takes in a number, in the Main window, in the Item window, Parameter Definition window, Parameters window, Method Definition window or the Estimation window, it can now take in a number, a calculation based on numbers, parameter references, calculations based on a parameter reference, or a calculation based on a combination of parameter references and numbers. When referring to a parameter the ID for that parameter found in the Parameter Definition window can be used, or an assigned Alias. In addition to this a syntax for easy definition of min/max for VCG, LCG and TCG is now available. It is possible to write =X4 in LCG_min or LCG_max and then ShipWeight will update LCG_min = LCG-2 and LCG_max = LCG+2. For VCG and TCG replace X with Z and Y. If this was not enough it is also possible to refer to the Weight and CoG for a given wgt. grp. To use the Weight and CoGs for a given wgt. grp. the syntax is as follows:

Weight: Wgt.grp|W Example: LW|W gives the Lightship weight

LCG: Wgt.grp |L Example: LW|L gives the Lightship LCG

VCG: Wgt.grp |V Example: LW|V gives the Lightship VCG

TCG: Wgt.grp |T Example: LW|T gives the Lightship TCG

Example 5:

In this example we will assign the Lightship Weight to a Parameter called Test. Then we will use this parameter to create a loading condition that is 10% load based on the total lightship weight. For this item we use the Lpp parameter to calculate the LCG and use the new syntax for equal distance from LCG to define the LCG_min and LCG_max.

Open the Parameter Definition window by selecting Database | Administrator | Parameter Definition from the Main window menu bar. Set up the Test Parameter as shown in the picture.


ID: te, Name: Test Description: “wgtgrp|W or V or T or L” Type: composite, Expression: LW|W

Parameter Definition


ID filter	Name filter	Alias filter	Description filter	Type filter	Decimals...	Unit filter	Symbol f...	Max filter	Alternatives filter	Expression filter	Act...
te											

A ID	Name	Alias	Description	Type	Decimals	Unit	Symbol	Max	Alternatives	Expression	Activ
te	test		wgtgrp W or V or T or L	composite	0			0.000		LW W	<input checked="" type="checkbox"/>

Click OK, when you have done this, and answer Yes to the question about reloading the parameter settings after it has changed.




Click on a weight group that can be used for the loading condition, for instance P-Provision and stores. Then open the Items window by clicking Items | List Items | Selected Weight Group... in the Main window menu bar.



Create a loading condition Item by using the Test Parameter we just created. Set the Factor to 0,1 to get 10% out of the Test Parameter and for Unit Weight write in =te.

WgtGrp	ItemNo	Description	RegUser	RegDate	NoOf [-]	Factor [-]	Length [-]	Width [-]	UnitWeight [kg]
P	1000	Loading conditon	Administrator	9/22/2021 3...	1	0.10	1.00	1.00	=te

Then we will define the LCG to be $L_{pp}/2$. It is now two options: 1. Use the Parameter ID for L_{pp} - IPE, or 2: Use the alias L created in Example 1 for L_{pp} . For using the Parameter ID the syntax is =IPE/2, and when using the alias the syntax is =L/2.



Items

Items Edit Setting Tools View Window

P - Provision and stores

ID & Description				
WgtGrp	ItemNo	Description	RegUser	RegDate
P	1000	Loading conditon	Administrator	9/22/2021 4:01

Weight & CoG											
NoOf [-]	Factor [-]	Length [-]	Width [-]	UnitWeight [kg]	Weight [kg]	VCG [m]	LCG [m]	TCG [m]	VCG_min [m]	VCG_max [m]	LCG
1	0.1	1	1	520130	52013	5	65	0	0	0	

Codes

test

Table view

	RegUser	RegDate	NoOf [-]	Factor [-]	Length [-]	Width [-]	UnitWeight [kg]	Weight [kg]	VCG [m]	LCG [m]
...	Administrator	9/22/2021 4...	1	0.10	1.00	1.00	520130.00	52013.00	5.00	=L/2

Then we will use the LCG functionality to set LCG_min and LCG_max. Write in =X4 in LCG_min, now LCG_min will be LCG-2 and LCG_max will be LCG+2.

Items

Items Edit Setting Tools View Window

P - Provision and stores

ID & Description				
WgtGrp	ItemNo	Description	RegUser	RegDate
P	1000	Loading conditon	Administrator	9/22/2021 4:01

Weight & CoG														
NoOf [-]	Factor [-]	Length [-]	Width [-]	UnitWeight [kg]	Weight [kg]	VCG [m]	LCG [m]	TCG [m]	VCG_min [m]	VCG_max [m]	LCG_min [m]	LCG_max [m]	TCG_min [m]	TCG_max [m]
1	0.1	1	1	520130	52013	5	65	0	0	0	63	67	0	0

Codes

test

Table view

	RegUser	RegDate	NoOf [-]	Factor [-]	Length [-]	Width [-]	UnitWeight [kg]	Weight [kg]	VCG [m]	LCG [m]	TCG [m]	VCG_min [m]	VCG_max [m]	LCG_min [m]	LCG_max [m]
...	Administrator	9/22/2021 4...	1	0.10	1.00	1.00	520130.00	52013.00	5.00	65.00	0.00	0.00	65.00	=X4	67.00

Updates to the help functionality

There have been updated more help functionality such as tooltips and explanatory text both in Items and Estimation window. E.g., when selecting more than one item in the Items window the tooltip will now show the count of selected items, and the total weight and CoG for those items. There are also added tooltips for custom codes and wgt.grp., showing the description, both in single record and table view.

Possible to overwrite existing project

It is now possible to overwrite an existing project in the Save As window.